



SERIES 3

SPECIFICATION DATA SHEET




Surface or Inset Mount Side Track



Recessed Side Track (Preconstruction)




"L" Mounting Bracket (Inset Option)




SRS Series 3 Housing

Tall Hem Bar



Hem Bar



Application Data		
o Interior/Exterior Use		
o Maximum: 12' (w) X 8' (h)		
o Low To Moderate Wind Application		
o Sun, Insect, Weather Or Privacy		
o Window and Patio		
o Advertising Display		
Fabrication Data		
o Registered ISO 9000/9001		
o Extruded Aluminum		
o Nylon Components		
o Powder Coat Finish		
o 2-1/4' Roller Tube		
o Stainless Steel Fasteners		
Standard Features		
o Extruded Aluminum Components		
o Side Track Retention System		
o Built In Dual Screen Cleaning System		
o Powder Coated Aluminum End Caps		
o Proprietary I Tube™ Roller Tube		
Optional Features		
o Hand Crank Drive System		
o Custom Colors For All Metal Parts		
o Recessed Side Tracks (Preconstruction)		
o "L" Brackets For Inside Mounting		
Electrical Data		
o AC Motor Specifications: 120 VAC/60Hz		
o 2 to 3 Amps		
o FCC Approved And UL Listed		
o Sony Altus 409 R2 RTS		
o Home Automation Interface Available		
Screen Options		
o Twitchell Super Insect And Solar Screen		
o Blackout Fabrics		
o Ferrari		
o Acrylics And Custom Graphics		
Graphics		
o Custom Prints Or SGS Graphics		
o 1 Or 2 Sides - Mesh Or Solid Fabric		
Standard Hardware Colors:		
o Black	o Green	o Silver
o Bronze	o Navajo	
o Brown	o Tan	
o Desert Sand	o White	
o Gray	o Bright White	

Special Notes:

When measuring the screen for an outside flush/surface mount, remember to allow for side tracks (each side is 2 1/4") and remember to allow for the height of your housing plus the height of the hem bar (1 7/8" plus brush size) so that nothing is in the opening. For inside mounting, always take the narrowest measurement and deduct 3/8" minimum to allow for fastening heads and "L" mounting channel thickness (this would be total for both sides). Always use longest measurement for calculating your drop. Fabric seams will always run horizontally. They are placed as high as possible unless otherwise stated. Seam placement is from the bottom of the hem bar up to the seam.